



ADHESION TESTS

The Key Indicator for Long Term Performance.



HIGHEST PERFORMING SYSTEMS. LOWEST APPLIED COST.



Step 1: Water and rag needed to prep surface for adhesion test.



Step 2: Wash substrate and allow to dry.



Step 3: Apply one coat of desired coating.



Step 4: Apply polyester fabric into first layer of coating.



Step 5: Apply second layer of coating over polyester fabric. Let cure for 2-3 days.



Step 6: Pull polyester fabric at a 90° angle to verify cohesive (pass) or adhesive (potential fail). Picture shows cohesive failure.

